




AEOTEC
BY AEON LABS

Water Sensor


View the expanded manual:
<http://aeot.ec/spprt/watersensor>



1 Aeotec by Aeon Labs Water Sensor

Your Z-Wave system is only as good as it is smart. Aeotec by Aeon Labs' Water Sensor brings it a new level of intelligence, one that is suited to both safety and convenience. Capable of detecting either the presence or absence of water to as little as 3% of an inch, each sensor is crafted into the smallest and most subtle of packages.

Familiarise yourself with your sensor



Package Contents:

- Water Sensor x1
- Iron Plate x1
- Screw x2
- AAA Battery x2
- Double-Sided Mounting Tape x2


2 Quick Start

Your Aeotec by Aeon Labs' Water Sensor is capable of detecting the presence or absence of water. Choosing the scenario you want will help you determine where best to place your sensor. The most common scenario is the detection of leaking water from the likes of a hot water system or an air conditioner. In other instances you may wish to detect when the level of water in a tank has decreased passed a certain level.


Prepare your Water Sensor

The first step is to activate your Water Sensor

1. Take out the back shell of Water Sensor



2. Remove the clear battery insulator by pulling it away from the Water Sensor




3. With the battery insulator removed, your Water Sensor powered and activated. It is now time prepare to install your Water Sensor.


Choosing a position for the Water probe

The following tips will help you select a position that will optimise the performance of your water probe.

- If detecting the presence of water, your probe's two prongs should sit flat against the surface where water will collect.




- If detecting the absence of water, your probe's two prongs should sit at the minimum water level you want.
- If detecting the absence of water, it's fine to submerge your probe in water - it's waterproof.



Choosing a position for the Water Sensor


The following tips will help you select a position that will optimise the performance of your Water Sensor.

- Your water sensor is not waterproof or weatherproof, as such you should not place it in any area where it is likely to get wet. This includes not placing it directly underneath objects which you may be monitoring for leaks, such as water heaters.



Keep Dry

- For an optimal wireless signal, position your Water Sensor 1 meter off of the ground.
- Additionally, for an optimal wireless signal mount your Water Sensor with its longest side vertical.
- Will have an optimal wireless signal when affixed 1 meter or above your home's floor.
- Placed within 30 meters of another Z-Wave device that is either a gateway or not powered by batteries.




- If outdoors should be protected from the elements - such as inside a recess or within a waterproof box

Installation your Water Probe

Once you've selected the best position for both parts of your Water Sensor to be installed, it's time to affix both to their respective surfaces.


1. Affixing your water probe's mounting plate

There is a magnet inside the water probe, if you've sure the position where your water probe should install, only adsorption your water probe up to a metal.



Metal


If you can't find the metal to affixing your water probe. Use the Iron plates .




1. installation your Water Sensor

Your water sensor's mounting plate can be affixed using screws or double-sided tape. You needn't worry about which end is the top or the bottom, they can be mounted with either end at the top - they're bidirectional.

- If using screws, attach your water sensor's mounting plate using the screws. If either surface is soft, plasterboard for instance, use the screw anchors.



- If mounting your water sensor indoors in an area where itself won't be exposed to condensation or moisture in the air, it is possible to use mounting tape to affix it to a wall. To begin, wipe the respective surface clean of any oil or dust. When the surface has dried, peel one side of the tape back and attach it to the corresponding section on the rear of main mounting plate.




3 Adding your Water Sensor to Z-Wave network

With your mounting plates prepared to hold each component of your sensor, it's time to add it to your Z-Wave network.

1. On the rear of your water sensor, remove the spacing tab to connect the batteries. Your water sensor's LED will blink for 3 seconds.
2. Press the Z-Wave button on your primary Z-Wave controller / gateway. If you're unsure of how to do this, refer to its user manual.
3. Press the Z-Wave button on your water sensor. If it has been successfully added to your Z-Wave network, its LED will

illuminate for 10 minutes. During this period your primary Z-Wave controller / gateway is able to configure your sensor.

- Your sensor will then automatically exit setup mode at the end of 10 minutes.



• Associate your Water Sensor with other Z-Wave devices

It's possible to use your Aeotec by Aeon Labs's Water Sensor to talk to more than just your gateway. As an example, you can create an automation activity that would activate a siren when water is detected.

Your Water Sensor is capable of directly controlling 5 other Z-Wave devices within your Z-Wave network. The following association steps are performed automatically if your primary Z-Wave controller / gateway is either a SUC (Static Update Controller) or a SIS (SUC ID Server). When this is the case, you'll need to create automation activities directly through your controller / gateway - refer to its user manual for further information.


- Set gateway sent Association set command, and Assign route command to Water Sensor.
- Then press and hold Z-Wave button of Water Sensor 3 seconds. Water Sensor will send wake up notification to gateway.
- After gateway received the wake up notification, Gateway will send preset commands to Water Sensor.

④ Remove your Water Sensor from Z-Wave network

Your sensor can be removed from your Z-Wave network at any time. You'll need to use the main controller in your Z-Wave network to do this. The following instructions tell you how to do this using Aeotec by Aeon Labs's Z-Stick and Minimote controllers. If you are using other products as your main Z-Wave controller, please refer to the part of their respective manuals that tells you how remove devices from your network.


• If you are using a Z-Stick

- If your Z-Stick is plugged into a gateway or a computer, unplug it.
- Take your Z-Stick to your sensor.
- Press the Z-Wave Button on your Z-Stick and hold for 3 seconds.
- Press the Z-Wave button on your sensor.
- If your sensor has been successfully removed from your network, its LED will blink for 3 seconds. If the removal was unsuccessful the light will be solid for 3 seconds after pressing your sensor's Inclusion button.
- Press the Z-Wave Button on the Z-Stick again to take it out of removal mode.



• If you are using a Minimote

- Take your Minimote to your sensor.
- Press Remove button on your Minimote.
- Press the Z-Wave button on your sensor.
- If your sensor has been successfully removed from your network, its LED will blink for 3 seconds. If the removal was unsuccessful the light will be solid for 3 seconds after pressing your sensor's Inclusion button.
- Press any button on your Minimote to take it out of removal mode.



④ Send wake up notification

In order to send your sensor new configuration commands from your Z-Wave controller or gateway, it'll need to be woken up.

- Remove your Water Sensor from its mounting plate by pressing down on the latch button and pulling it away from its mounting plate.
- Press the Wake-up Button 3 times quickly on the rear of your sensor. Your sensor will now remain awake for 10 minutes.
- When done, return your Water Sensor to its mounting plate. To do this align the plate's hitch with your sensor's hitch hole, and push the top of your sensor into the mounting plate until the two parts click firmly together.

⑤ Reset all your sensor's configurations

Should you wish to reset all your sensor's configurations, you are able to reset it to its factory defaults.

- Press and hold the Z-Wave button on the rear of your Water Sensor for 20 seconds.
- Your Water Sensor will reset to its factory default configuration. Its LED will blink for 3 seconds to let you know it was reset successfully.

Your water sensor's configurations will also be reset to factory defaults if you remove it from your Z-Wave network.

⑥ Technical specifications

Operating distance: Up to 100 feet / 30 meters indoors and 300 feet / 100 meters outdoors.

Operating temperature: -35°C to +60°C.

⑦ Warranty

Aeon Labs warrants to the original purchaser of Products that for the Warranty Period (as defined below), the Products will be free from material defects in materials and workmanship. The foregoing warranty is subject to the proper installation, operation and maintenance of the Products in accordance with installation instructions and the operating manual supplied to Customer. Warranty claims must be made by Customer in writing within thirty (30) days of the manifestation of a problem. Aeon Labs' sole obligation under the foregoing warranty is, at Aeon Labs' option, to repair, replace or correct any such defect that was present at the time of delivery, or to remove the Products and to refund the purchase price to Customer.

The "Warranty Period" begins on the date the Products is delivered and continues for 12 months.

Any repairs under this warranty must be conducted by an authorized Aeon Labs service representative and under Aeon Labs' RMA policy. Any repairs conducted by unauthorized persons shall void this warranty.

Excluded from the warranty are problems due to accidents, acts of God, civil or military authority, civil disturbance, war, strikes, fires, other catastrophes, misuse, misapplication, storage damage, negligence, electrical power problems, or modification to the Products or its components.

Aeon Labs does not authorize any person or party to assume or create for it any other obligation or liability in connection with the Products except as set forth herein.

Aeon Labs will pass on to Customer all manufacturers' Material warranties to the extent that they are transferable, but will not independently warrant any Material.

Customer must prepay shipping and transportation charges for returned Products, and insure the shipment or accept the risk of loss or damage during such shipment and transportation. Aeon Labs will ship the repaired or replacement products to Customer freight prepaid.

Customer shall indemnify, defend, and hold Aeon Labs and Aeon Labs' affiliates, shareholders, directors, officers, employees, contractors, agents and other representatives harmless from all demands, claims, actions, causes of action, proceedings, suits, assessments, losses, damages, liabilities, settlements, judgments, fines, penalties, interest, costs and expenses (including fees and disbursements of counsel) of every kind (i) based upon personal injury or death or injury to property to the extent any of the foregoing is proximately caused either by a defective product (including strict liability in tort) or by the negligent or willful acts or omissions of Customer or its officers, employees, subcontractors or agents, and/or (ii) arising from or relating to any actual or alleged infringement or misappropriation of any patent, trademark, mask work, copyright, trade secret or any actual or alleged violation of any other intellectual property rights arising from or in connection with the products, except to the extent that such infringement exists as a result of Aeon Labs' manufacturing processes.

IN NO EVENT SHALL AEON LABS BE LIABLE FOR ANY INDIRECT, INCIDENTAL, PUNITIVE, SPECIAL OR CONSEQUENTIAL DAMAGES, OR DAMAGES FOR LOSS OF PROFITS, REVENUE, OR USE INCURRED BY CUSTOMER OR ANY THIRD PARTY, WHETHER IN AN ACTION IN CONTRACT, OR TORT, OR OTHERWISE EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. AEON LABS' LIABILITY AND CUSTOMER'S EXCLUSIVE REMEDY FOR ANY CAUSE OF ACTION ARISING IN CONNECTION WITH THIS AGREEMENT OR THE SALE OR USE OF THE PRODUCTS, WHETHER BASED ON NEGLIGENCE, STRICT LIABILITY, BREACH OF WARRANTY, BREACH OF AGREEMENT, OR EQUITABLE PRINCIPLES, IS EXPRESSLY LIMITED TO, AT AEON LABS' OPTION, REPLACEMENT OF, OR REPAYMENT OF THE PURCHASE PRICE FOR THAT PORTION OF PRODUCTS WITH RESPECT TO WHICH DAMAGES ARE CLAIMED. ALL CLAIMS OF ANY KIND ARISING IN CONNECTION WITH THIS AGREEMENT OR THE SALE OR USE OF PRODUCTS SHALL BE DEEMED WAIVED UNLESS MADE IN WRITING WITHIN THIRTY (30) DAYS FROM AEON LABS'S DELIVERY, OR THE DATE FIXED FOR DELIVERY IN THE EVENT OF NONDELIVERY.

THE INDEMNITY AND WARRANTY IN ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER INDEMNITIES OR WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

• FCC NOTICE (for USA)

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

• Warning

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.

Contact your local government for information regarding the collection systems available.

• Certifications (regional):



Version:501004500001-AA

www.aeotec.com

